

Use the **ON** button to start the projector. Please remember that the projector will warm up as it goes on, so do not expect a bright light immediately.

Select the source for the signal (it may take a few seconds for the projector to respond):

Note: If you select a source and it does not appear on the screen, use the **Proj. Mode** button to toggle the projector between video sources.

- Button 1: VCR Once selected, the projector will automatically select the correct video source. The VCR can be controlled from the bottom row of the panel on the right of the controller. Use the volume control to adjust the sound level.
- Button 1: DVD Once selected, the projector will automatically select the correct video source. You may need to press the button several times to adjust the projector to the correct source. The DVD can be controlled from the panel on the right of the controller. Use the volume control to adjust the sound level.
- Button 3: Aux Video This is the input on the side of the controller facing the classroom
 with three RCA connectors similar to what you see on a television. It is designed to take
 the signal from a video camera, microscope, or any other device with and RCA video
 output.
- Button 4: VGA This is also on the side of the box facing the classroom. It is designed
 to take in a video signal from a document camera, microscope, or any other device with
 a 15 pin VGA output.
- Button 5: Laptop This is the selection if you are showing a presentation from your laptop. In the cable cubby next to the controller you will find the VGA cable, along with network and sound cables. Press Button 6. You may need to press the button several times to adjust the projector to the correct source. If you are using the network, plug the cable into your network port. For sound from your computer through the system, use the mini plug in the audio output jack on your computer and the volume control on the controller. You may need to mirror your computer to the projector.
- Button 6: Document Camera Select this source to view the items on the document camera.

To turn the system off, press the **OFF** button. The lamp should go out, leaving the fan running for a few minutes to cool off the projector.